


TYPE "A"




TYPE "B"

WATER GAP DETAILS

NOTES:

1. Used where fence alignment changes are 5 degrees or greater, but less than 10 degrees.
2. Used at bottom of sharp vertical breaks to prevent uplift from removing normally set post.



ANCHOR POST

NOTES:

1. Used where fence alignment changes are 5 degrees or greater, but less than 10 degrees.
2. Used at bottom of sharp vertical breaks to prevent uplift from removing normally set post.

